



#### SIGNAL LINES

- |  |                                    |  |                         |
|--|------------------------------------|--|-------------------------|
|  | : MAIN SIGNAL LINE                 |  | : DVD AUDIO SIGNAL LINE |
|  | : CD-DA (AUDIO /VIDEO) SIGNAL LINE |  | : DVD VIDEO SIGNAL LINE |

( ) Indicates the Pin No. of Right Channel.

NOTE : Signal Lines are applicable to the Left Channel only.